



CRAZY SIZE CHART

EURO / CRAZY SIZING	35	36	37	38	39	40	41	42	43	44	45	46	47
Crazy skates have heat-adjustable shapes, including width and arches.													
adjusted mm	+1.5mm	235.9	242.5	249.2	255.8	262.5	269	275.8	282.5	289.1	295.7	302.4	309
adjusted inches	+.39in	8.95	9.21	9.48	9.74	10	10.26	10.52	10.79	11.05	11.31	11.57	11.83
UK shoe	3	-	4	5	6	7	-	8	9	10	11	12	13
US Men's shoe (most US skate sizes)	-	4	5	6	7	-	8	-	9	10	11	12	13
US Women's shoe	4	5	6	7	8	-	9	-	10	11	12	13	14
Total length of outside of skate sole in mm		237.4	244	250.7	257.3	264	270.5	277.3	284	290.6	297.2	303.9	310.5
Total length of outside of skate sole in inches		9.34	9.6	9.87	10.13	10.39	10.65	10.91	11.18	11.44	11.7	11.96	12.22

How to use this chart: Measure your feet standing, in socks, in the evening (when your feet are largest, and when most people practice). To get an accurate length measurement, make sure you measure from the farthest back on your heel to your longest toe. Then measure width around the widest part of your foot - all the way around. Compare those measurements to your shoe size to check for accuracy, keeping in mind that most people wear shoes looser than skates.

Then line up your measurements from the blue boxes to your skate size in the green box.

* PLEASE NOTE: Crazy sent us a chart that measures the entire length of the outside of the sole (in gray), so we measured our feet and sizes and found that an adjusted 1.5mm / .4" charted accurately for sizes 35-40. No one here wears larger than size 40, so we have not yet been able to validate the larger sizes. Please take that into account when using this chart. Another thing to consider is that every skater at Sin City wears their skates very snug; more so than their shoes.